

Data Projector

Operating Instructions for **Memory Stick**



VPL-CX85

Table of Contents

Overview

Features	4
Precautions	4
About This Manual	4
About a Memory Stick	5

Setting Up

Using the Memory Stick	9
Operating the Memory Stick Home	10

Viewing the Slide

Sliding Material for a Presentation — Presentation Viewer	11
Executing the Slide Show Promptly	12
Switching the File Display Mode	12
Repeating the Slide Show	13
Starting a slide show from the selected index picture	13
Setting the Autorun Function	13
Sliding a Picture File — Picture Viewer	14
Starting a slide show from the selected index picture	16
Displaying a picture file on the full screen	16
Executing the Slide Show Promptly	16
Playing Back a Movie File	16
Executing the Slide Show Promptly	18

Setting/Displaying the Picture File

Operating the Picture File	19
Protecting an Important File	22
Rotating a Picture File	22
Registering a File as the Startup Picture	22
Deleting a Picture File	22
Showing/Hiding the Picture File Information	22
Switching the Sound of a Movie File	23
Sorting the Picture Files	23
Displaying Still Picture Files or Movie Files Only	23

Useful Settings

Displaying the Picture Files Recorded by a Digital Camera Only	24
Starting a Presentation Automatically — Autorun	25
Projecting a Selected File When the Power is Turned on — Startup	26

Operating Memory Stick

Displaying the Memory Stick Information	27
Formatting a Memory Stick	27

Other

Troubleshooting	28
-----------------------	----

Features

When you memorize presentation material converted by the Projector Station for Presentation (supplied software) or a picture file recorded by a digital camera in the **Memory Stick**, you can easily make effective presentations without a computer.

Presentation Viewer

After you have converted Microsoft PowerPoint files by the Projector Station for Presentation to a file which offers the most advantages for projection on the projector, you can make a slide show.

Picture Viewer

You can make the slide show or display on the screen by using a JPEG still picture file (DCF¹⁾-compatible) recorded by a digital camera and an MPEG1 movie file recorded by Sony MPEG MOVIE etc. You can set the effect of the slide when it is displayed, and the way (automatic or manual) the slide is exchanged.

Usable MPEG1 files: MPEG MOVIE, MPEG MOVIE AD, MPEG MOVIE EX, MPEG MOVIE HQ, MPEG MOVIE HQX, MPEG MOVIE CV, MPEG1 of VAIO Giga pocket (equivalent to a Video CD)

1) DCF: Design rules for Camera File systems

Digital Camera Mode

This unit can choose and display JPEG and MPEG1 picture files recorded by a digital camera (DCF-compatible) only from among picture files stored in a **Memory Stick**.

Autorun

When the **Memory Stick** with the picture file for which the Autorun function is set by the Projector Station for Presentation or in Memory Stick Home is inserted in the Memory Stick slot, the input is automatically switched to Memory Stick and the slide show starts.

Startup

When the power is turned on, the selected picture file is projected for about 30 seconds. You can adjust the focus and zoom without a signal from other equipment.

You can also select the original picture or the registered picture file in the **Memory Stick**.

Precautions

- To prevent data loss, make backups of data frequently. In no event will Sony be liable for any loss of data.
- Unauthorized recording may be contrary to the provisions of copyright law.
- The Memory Stick application software may be modified or changed by Sony without prior notice.

About This Manual

This manual explains the operations for viewing the picture files stored in the **Memory Stick**.

For details on making the presentation material, see the Operating Instructions of the Projector Station for Presentation (CD-ROM, supplied).

*For operations other than by the **Memory Stick**, see the supplied Operating Instructions.*

About a Memory Stick

On Memory Sticks

Memory Stick is a new compact, portable and versatile IC recording medium with a data capacity that exceeds that of a floppy disk. **Memory Stick** is specially designed for exchanging and sharing digital data among Memory Stick compatible products. Because it is removable, **Memory Stick** can also be used for external data storage.

Memory Stick is available in two sizes: standard size and compact **Memory Stick Duo** size. Once attached to a Memory Stick Duo adapter, **Memory Stick Duo** reverts to the same size as standard **Memory Stick** and thus can be used with products compliant with standard **Memory Stick**.

Types of Memory Sticks

Memory Stick is available in the following six types to meet various functional requirements.

- **Memory Stick PRO**
Equipped with the MagicGate copyright protection technology and can be used only with Memory Stick PRO compliant products.
- **Memory Stick**
Memory Stick stores any type of data except copyright-protected data that requires the MagicGate copyright protection technology.
- **Memory Stick** (compatible with MagicGate/high speed data transfer)
Equipped with the MagicGate copyright protection and compatible with high speed data transfer. This **Memory Stick** can be used with all Memory Stick compliant products. The projector is not compatible with the high speed data transfer function of this **Memory Stick**.
- **MagicGate Memory Stick**
Equipped with the MagicGate copyright protection technology.

- **Memory Stick-ROM**
Memory Stick-ROM stores pre-recorded, read-only data. You cannot record on **Memory Stick-ROM** or erase pre-recorded data.
- **Memory Stick** (with memory select function)
This is a **Memory Stick** that has (128MB) plural memory in it. You can select memory to use for whatever purposes through the memory select switch on the back of the **Memory Stick**.
You cannot use all the available memory at the same time and/or continuously.

Available types of Memory Stick for the projector

Memory Stick Media Compatibility Chart

	Recording/Playback
Memory Stick Memory Stick (with memory select function) Memory Stick Duo	○
Memory Stick (compatible with MagicGate/high speed data transfer) Memory Stick Duo (compatible with MagicGate/high speed data transfer)	○*1*2
Memory Stick-ROM	playback only
MagicGate Memory Stick MagicGate Memory Stick Duo	○*1
Memory Stick PRO Memory Stick PRO Duo	○*1

*1: Data recording/playback that requires MagicGate functions cannot be performed.

*2: Does not support high speed data transfer using a parallel interface.

- When using a **Memory Stick Duo** in the projector, always insert the **Memory Stick Duo** into the Memory Stick Duo adapter sold separately. If you insert a **Memory Stick Duo** without the Memory Stick Duo adapter, you may be unable to remove the **Memory Stick Duo**.
- Not all types of **Memory Stick** media are guaranteed to operate.

Note on Memory Stick PRO and Memory Stick (compatible with MagicGate/high speed data transfer)

Memory Stick PRO and **Memory Stick** (compatible with MagicGate/high speed data transfer) do not support high speed data transfer using a parallel interface.

Note on Memory Stick (compatible with MagicGate/high speed data transfer)

Transfer speed when using **Memory Stick** (compatible with MagicGate/high speed data transfer) varies and is dependent upon Memory Stick compliant products.

Note on memory capacity of Memory Stick PRO

Memory Stick PRO features vary by and are dependent upon the design of host hardware devices.

Memory Stick PRO Media slot:

- does not support MagicGate copyright protection technology;
- does not support access control security function.

This device has been demonstrated as operable with up to 1GB **Memory Stick**. Operation is not guaranteed for **Memory Stick PRO** beyond this capacity.

Note on Memory Stick Duo/Memory Stick PRO Duo

- To use a **Memory Stick Duo/Memory Stick PRO Duo** with this unit, attach it to a Memory Stick Duo adapter before inserting it into the unit.

If you insert a **Memory Stick Duo/Memory Stick PRO Duo** without the Memory Stick Duo adapter, you may be unable to remove the **Memory Stick Duo/Memory Stick PRO Duo**.

- Make sure to attach a **Memory Stick Duo/Memory Stick PRO Duo** to the adapter in the right direction.
- Make sure to insert a Memory Stick Duo adapter in the right direction. Otherwise, the unit may be damaged.
- Do not insert a Memory Stick Duo adapter without a **Memory Stick Duo/Memory Stick PRO Duo** attached. Doing so may result in malfunction of the unit.

Available File Capacity

This unit is designed to be capable of playing a file with a capacity of less than 2 GB stored in the **Memory Stick**.

Note on data read/write speed

Data read/write speed may vary depending on the combination of the **Memory Stick** and Memory Stick compliant product you use.

Note on Access Control

This unit cannot read **Memory Stick** that has Access Control with other units. To read/write data on the Access Control **Memory Stick**, unlock the **Memory Stick** with the unit that has locked it.

Note on Memory Stick (with memory select function)

- You cannot use all the available memory at the same time and/or continuously.
- Do not use the memory select switch while the **Memory Stick** is connected to any compatible device that is compatible for use with this feature, as this may cause a malfunction. If you use the memory select function while the **Memory Stick** is connected to any compatible device and there is a malfunction, we will not honor the guarantee.

- When using the memory select switch, make sure to firmly move the switch to the end. If you do not switch it completely, it may cause a problem or malfunction.
- Check your memory selection on **Memory Stick** before inserting it into the Memory Stick slot of the compatible device.
- When you use **Memory Stick** with memory select function, you can choose the type of memory by switching the memory select switch. As the compatible device will only access the memory selected by you, note the following:
 - A formatting (initializing) process is executed for the selected memory only.
 - Remaining memory display reflects only selected memory information.
 - Error display reflects only selected memory information.
 Each memory is handled individually by selecting it.

On MagicGate


MagicGate is copyright protection technology that uses encryption technology.

Format to save a file

Material for a presentation converted by the Projector Station for Presentation is saved in the following file formats in the **Memory Stick**.

- Image files (DCF-compatible) compressed in the JPEG (Joint Photographic Experts Group) format (extension .jpg).
- The Sony Projector Presentation file (SPP file), which is an original file format of Sony. This file integrates information such as destination and setting information of the image file, etc.

Before using a Memory Stick



- When you set the **Memory Stick** erasure prevention switch to **Lock**, data cannot be recorded, edited, or erased.
- Use a sharp object, such as a ballpoint pen, to move the **Memory Stick Duo/Memory Stick PRO Duo** erasure prevention switch.
- Data may be damaged if:
 - You remove the **Memory Stick** or turn off the unit while it is reading or writing data.
 - You use the **Memory Stick** in a location subject to the effects of static electricity or electric noise.
- We recommend that you make a backup copy of important data that you record on **Memory Stick**.

Notes

- Do not attach anything other than the supplied label to the **Memory Stick** labeling position.
- Attach the label so that it does not stick out beyond the labeling position.
- Do not write forcefully on **Memory Stick Duo/Memory Stick PRO Duo** memo area.
- Carry and store the **Memory Stick** in its case.
- Do not touch the terminal of the **Memory Stick** with anything, including your finger or metallic objects.
- Does not strike, bend, or drop the **Memory Stick**.
- Do not disassemble or modify the **Memory Stick**.
- Do not allow the **Memory Stick** to get wet.
- Do not use or store the **Memory Stick** in a location that is:
 - Extremely hot, such as in a car parked in the sun

(Continued)

- Under direct sunlight
- Very humid or subject to corrosive substances

About formatting Memory Sticks

When **Memory Sticks** are shipped from the factory, they are already formatted to a special standard. When you format **Memory Sticks**, we recommend formatting them on this unit.

Caution when formatting Memory Sticks on a personal computer

Pay attention to the following points when formatting **Memory Sticks** on a personal computer.


Operation of **Memory Sticks** formatted on a personal computer is not guaranteed on this unit. To use a **Memory Stick** that has been formatted on a personal computer, the **Memory Stick** must be reformatted on this unit. If it is not reformatted, all data stored on **Memory Stick** will be lost.

Notes on image data compatibility

Image data files saved to a **Memory Stick** by using the software conforming to the Design Rules for Camera File Systems universal standard established by JEITA (Japan Electronics and Information Technology Industries Association). JPEG files converted by Adobe Photoshop, etc. must be converted to JPEG format (DCF-compatible) again by the Projector Station for Presentation.


Access Lamp

If the access lamp is turned on or is flashing, data is being read from or written to the **Memory Stick**. At this time, do not shake the computer or projector or subject them to shock. Do not turn off the power of the computer and projector or remove the **Memory Stick**. This may damage the data.

-
- Microsoft and PowerPoint are registered trademarks and trademarks of Microsoft Corporation in the United States and/or other countries.
 - Adobe and Photoshop are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and /or other countries.
 - Compact Flash is a registered trademark of the ScanDisk Corporation in the United States.
 - **Memory Stick** and  are trademarks of Sony Corporation.
 - **Memory Stick Duo** and **MEMORY STICK DUO** are trademarks of Sony Corporation.
 - **Memory Stick PRO** and **MEMORY STICK PRO** are trademarks of Sony Corporation.
 - **Memory Stick PRO Duo** and **MEMORY STICK PRO DUO** are trademarks of Sony Corporation.
 - **Memory Stick-ROM** and **MEMORY STICK-ROM** are trademarks of Sony Corporation.
 - **MagicGate Memory Stick** is trademark of Sony Corporation.
 - **MagicGate** and **MAGICGATE** are trademarks of Sony Corporation.

Using the Memory Stick

Insert the **Memory Stick** into the Memory Stick slot on the side of the projector.




Notes

- Insert the **Memory Stick** with the arrow mark pointing toward the Memory Stick slot.
- Do not insert the **Memory Stick** into the wireless LAN card slot.
- You cannot insert the **Memory Stick** into the wireless LAN card slot even if you use the Memory Stick Duo adapter compliant with the Compact Flash slot.

To remove the Memory Stick


When the access lamp is turned off, press the **Memory Stick** and remove your hand. As the lock is released, remove the **Memory Stick**.




Operating the Memory Stick Home

The initial display for Memory Stick input is the Memory Stick Home. The Memory Stick Home is used for setting and executing an event (e.g., selecting the viewer), setting the Autorun and Startup and formatting the **Memory Stick**. The guide for the key operation is displayed at the bottom of the Memory Stick Home display. Use the Remote Commander or the control panel for setting. The selected item is displayed in yellow.

For details on each operation, see the relevant page.





- 1 Press the  key to select Memory Stick. The Memory Stick Home appears.


Memory Stick Home mark



Title or folder name for the selected contents

First picture file of the selected content


- 2 Use the  or  key to select the desired item, then press the ENTER key.
- 3 Use the  or  key to make the setting for an item, then press the ENTER key.




Sliding Material for a Presentation — Presentation Viewer


After you have converted Microsoft PowerPoint files by the Projector Station for Presentation to a file which offers the most advantages for projection on the projector, you can make a slide show.

For details on making the presentation material, see the Operating Instructions of the Projector Station for Presentation (CD-ROM, supplied).


- 1 Press the  key to select Memory Stick.
The Memory Stick Home appears.






- 2 Select “Select”, then press the ENTER key.
A drop-down list appears.




- 3 Select “Presentation Viewer”, then press the ENTER key.
- 4 Select “Select Folder”, then press the ENTER key.
The Select Folder menu appears.



The Presentation Viewer can select the “contents” in units of a folder in which multiple JPEG files are contained. In the above illustration, there are three lots of contents of presentation material: Presentation 1, Presentation 2 and Presentation 3.


To select the contents which are not displayed, press the  key to select the slider in the Select Folder menu and press the  or  key. The next three lots of contents appear.

- 5 Select the contents for the presentation, then press the ENTER key.
The title name of the selected presentation material and the first picture file is displayed.




- 6 Select “Slide Show”, then press the ENTER key.
- 7 Select “Start”, then press the ENTER key.

To execute the slide show

When the slide show setting is set to “Auto” by the Projector Station for Presentation, the slide show is executed according to the settings made by the Projector Station for Presentation. When you want to end the slide show, press the  or ENTER key. When the slide show setting is set to “Manual”, press the following keys for the slide show.

➡ : to display the next slide





⬅ : to display the previous slide

 : to end the slide show

To return to Memory Stick Home before executing the slide show

Select “Close” to return to Memory Stick Home before executing the slide show in Step 6 of “Sliding Material for a Presentation.”

Executing the Slide Show Promptly

As the settings are memorized even if you change the input after the setting of steps 1 to 5 of “Sliding Material for a Presentation — Presentation Viewer”, press the  key on the Remote Commander just as you start the presentation. The input is changed to Memory Stick. Press the  key again and the slide show starts promptly. To end the slide show, press the  or ENTER key when the slide show setting is “Auto”, or press the  key when the slide show setting is “Manual”.

Switching the File Display Mode

You can display one picture file only (Normal mode) or thumbnails of picture files (Thumbnail mode).

- 1 Select “Index Display” in Memory Stick Home, then press the ENTER key.
- 2 Select the setting, then press the ENTER key.
Normal: to display a picture file
Thumbnail: to display thumbnails of the picture files contained in the selected contents.

Repeating the Slide Show

- 1 Select “Slide Show” in Memory Stick Home, then press the ENTER key.
- 2 Select “Repeat”, then press the ENTER key.
On : set to execute the slide show repeatedly
Off : set to execute the slide show one time only

Starting a slide show from the selected index picture


You can run a slide show by selecting a thumbnail in the normal or thumbnail display mode.

- 1 Press the **↑**, **↓**, **←** or **→** key to select the picture file from which you want to start the slide show, and press the ENTER key.
- 2 Press the **↑** or **↓** key to select “Slide Show” in the picture setting menu, and press the ENTER key.

Setting the Autorun Function

When you store the presentation file for which the Autorun function is set in the **Memory Stick** and insert it in the Memory Stick slot on the projector, the input channel is automatically switched to Memory Stick and the slide show starts.

- 1 Select the title of the file you want to use for your presentation in Memory Stick Home, then press the ENTER key.
- 2 Select “Autorun”, then press the ENTER key.



- 3 Select the item you want to set, then press the ENTER key.
Set : set the Autorun function for the file.
Cancel : cancel the Autorun function of the file.
Close : when you do not set the Autorun function for the file.

Notes


- You can set the Autorun function for only one presentation file per **Memory Stick**.
- To use the Autorun function, set “Autorun” to “On” as described in “Starting a Presentation Automatically — Autorun” on page 25.

Sliding a Picture File — Picture Viewer


You can make a slide show by using still picture files (DCF-compatible) in the JPEG format recorded by a digital camera or movie picture files in the MPEG1 format recorded by Sony MPEG MOVIE etc.

For details on operations regarding the picture files, see “Operating the Picture File” on page 19.


- 1 Press the  key to select the Memory Stick. Memory Stick Home appears.






- 2 Select “Select”, then press the ENTER key. A drop-down list appears.




- 3 Select “Picture Viewer”, then press the ENTER key. Thumbnails of the picture files contained in the selected folder appear.



-  : Appears when a file is protected.
-  : Appears when a startup file is set.
-  : Movie icon

- 4 Select “Select Folder”, then press the ENTER key. The Select Folder menu appears.




To upper stage

Folders included in the current folder

Current folder


First picture file in the current folder

- 5 Select the current folder using the ↓ or ↑ key, then press the → key to select the Select Folders menu.



- 6 Select the folder for your presentation, then press the ENTER key. The title name and the first picture file of the selected folder are displayed. To select the folders which are not displayed, press the → key to select the slider in the Select Folders menu and press the ↓ or ↑ key. The next 10 folders appear.


- 7 Select “Slide Show” in Memory Stick Home, then press the ENTER key.




- Effect** : set the effect when the slide is displayed
- Adv. Slids.** : set automatic or manual slide
- Interval** : set the period for which one slide is displayed. The time is approximate. When “Advan. Slids.” is set to “Manual”, it does not work.
- Repeat** : set to execute the slide show repeatedly or one time only.

- 8 Select each item, then press the ENTER key.
- 9 Set each item, then press the ENTER key.
- 10 Select “Start”, then press the ENTER key.

To execute the slide show

When “Advan. Slids.” in the slide show setting is set to “Auto”, the slides change automatically. When a movie file is selected, the movie plays back automatically, and after playback the next slide is displayed automatically. When you want to end the slide show, press the  or ENTER key. When it is set to “Manual”, press the following keys for the slide show.

- : to display the next slide
- ← : to display the previous slide
-  : to end the slide show

When “Advan. Slids.” is set to “Manual”, the movie is not played back and the first picture is displayed for a movie file. By pressing the → key the next slide is displayed. To play back the movie, see “Playing Back a Movie File” on page 16.

To return to Memory Stick Home before executing the slide show

Select “Close” to return to Memory Stick Home before executing the slide show in Step 9 of “Sliding a Picture File — Picture Viewer”.


Starting a slide show from the selected index picture

You can run a slide show by selecting a thumbnail in the normal or thumbnail display mode.

- 1 Press the **↑**, **↓**, **←** or **→** key to select the picture file from which you want to start the slide show, and press the ENTER key.
- 2 Press the **↓** or **↑** key to select “Slide Show” in the picture setting menu, and press the ENTER key.


Displaying a picture file on the full screen

- 1 Select a picture file in the thumbnail display, then press the ENTER key.
- 2 Select “Full Screen”, then press the ENTER key.
The selected picture file is enlarged on the full screen.







To execute the slide show with the picture on the full screen

Press the following keys.

- : to display slides forward. (The slide show ends at the last picture file.)
- ←** : to display slides backward. (The slide show ends at the first picture file.)
-  : to return to Memory Stick Home

Executing the Slide Show Promptly

As the settings are memorized even if you change the input after the setting of steps **1** to **9** of “Sliding a Picture File — Picture Viewer”, press the  key on the Remote Commander just as you start the presentation. The input is changed to Memory Stick. Press the  key again and the slide show starts promptly. To end the slide show, press the  or ENTER key when “Advan. Slids.” is set to “Auto”, or press the  key when “Advan. Slids.” is set to “Manual”.

Playing Back a Movie File


You can play back a movie using the Movie Player displayed on the screen when “Advan. Slids.” is set to “Manual”. You can also start movie playback by selecting a movie file in the thumbnail display mode.

Notes

- The Movie Player cannot be displayed when “Advan. Slids.” is set to “Auto”.
- The unit can play back an MPEG1 movie file recorded by the Sony MPEG MOVIE, etc. (Movies may occasionally skip when you watch them.)
Usable MPEG1 files: MPEG MOVIE AD/EX/HQ/HQX/CV, MPEG1 of VAIO Giga pocket (equivalent to a video CD).

- 1 Follow steps **1** to **7** of “Sliding a Picture File — Picture Viewer”.

- Set “Advan. Slids.” to “Manual” in the Slide Show setting menu.



- Press the ENTER key.
- Select “Start”, then press the ENTER key.


To execute the slide show

Press the following keys:

- ➡ : to display the next slide
- ⬅ : to display the previous slide
- ⏏ : to end the slide show

When a movie file is selected by pressing the ⬅ or ➡ key, the Movie Player appears on the screen. Operate the Movie Player as follows:

[Movie Player]



- ▶ (play/pause) : to play back. During playback, the button display is changed to the || (pause) button.
- (stop) : to stop playback
- Full Screen** : to play back on the full screen
- Menu** : to display the index screen

[Guide display]

- ⬅ **Prev.** : to display the previous slide in the movie pause mode. During playback, the guide display is changed to ⬅ **Rew** (rewind).
- ➡ **Next** : to display the next slide in the movie pause mode. During playback, the guide display is changed to ➡ **FF** (fast forward).

To play back a movie

Press ▶.

Playback starts. When the playback is finished, playback stops with the first picture of the movie file displayed. To stop the playback momentarily, press the ↓ key to select ■, then press the ENTER key.

To play back on the full screen

Select “Full Screen”, then press the ENTER key.

The picture is enlarged on the full screen and playback starts.




When you press the ↑, ↓, ⬅, ➡ or ENTER key during playback, the Movie Player reappears on the screen.

Note

When the picture size is small, it is not enlarged on the full screen if you select “Full Screen”.

To return to Memory Stick Home without executing the movie play
Select “Return”.

Executing the Slide Show Promptly

As the settings are memorized even if you change the input after the setting of steps **1** to **3** of “Playing Back a Movie File”, press the  key on the Remote Commander just as you start the presentation. The input is changed to Memory Stick. Press the  key again and the slide show starts promptly. To end the slide show, press the  key.

To start full-screen playback when the thumbnails are displayed

- 1** Select a movie file, then press the ENTER key.
The index screen appears (see page 20.)
- 2** Select “Movie Player”, then press the ENTER key.
The Movie Player appears.
- 3** Select “Full Screen”, then press the ENTER key.
Playback starts automatically.

To operate the movie file

Select “Menu” in the Movie Player, then press the ENTER key.
The index screen is displayed. Using the index screen, you can show or hide the movie file information, switch the sound, protect important movie files, or delete unnecessary movie files.

For details on operations of the index screen, see “Operating the Picture File” on page 19.

Operating the Picture File

To operate the picture file, display the index screen (see pages 20 and 21.)

When the Presentation Viewer is displayed

To display the index screen, select the contents in the normal or thumbnail display mode, then press the ENTER key.

You can execute the slide show or enlarge a picture file on the full screen using the menu on the index screen. If you press the ENTER key when a full-screen picture is displayed, you can show or hide the picture file information.

When the Picture Viewer is displayed

The possible operations depend on the type of picture file to be selected (still picture/movie).

When “Thumbnail” is selected for “Index Display”

To display the index screen, select a thumbnail, then press the ENTER key. You can perform the following operations using the menu on the index screen: displaying a picture file on the full screen, executing a slide show, protecting an important picture file, rotating a picture file (still picture only), registering the startup picture file (still picture only) and deleting a picture file.

When a full-screen still picture file is selected

To display the index screen, press the ENTER key when the picture is displayed on the full screen.

You can perform the following operations using the menu on the index screen: showing/hiding the picture file information, protecting an important picture file, rotating a picture file, registering the startup picture file and deleting a picture file.

When a movie file (Movie Player) is selected


To display the index screen, select “Menu” on the Movie Player.

You can perform the following operations using the menu on the index screen: showing/hiding the movie file information, switching the sound, protecting an important movie file and deleting a movie file.


For details on the use of the index screen, see the relevant page.



Index screen of a still picture file



Index screen of a movie file



To select a picture file in the thumbnail display mode, press the **↑**, **↓**, **←** or **→** key.


If you want to display other picture files when more than 16 picture files are contained in the current content, select a picture file displayed in the bottom row and press the **↓** key, or select a picture file displayed in the right-most column, press the **→** key to select the slider, then press the **↓** key.

To start the slide show, press the **⏮** key in the index screen. The slide show begins from the selected picture file.

Index screen of a full-screen still picture file

Appears when the Picture Viewer is displayed

Order of the current content/
Total number of picture files
in the current content



Resolution Date

Appears when a startup file is set


File name and file format

Appears when a file is protected

If you want to display another picture file when multiple picture files are contained in the current content, press the **➡** key. To return to Memory Stick Home, press the **⏪** key in the index full screen.

Movie Player

Movie icon



Resolution Date

Order of the current content/
Total number of picture files
in the current content

File name and file format

Appears when a file is protected



Protecting an Important File

After selecting the file you want to protect, set “Protect” to “On” or “All On”. When a file is protected, the protect mark is displayed.

Rotating a Picture File

After selecting the file you want to rotate, set “Rotate”. The picture rotates 90° on every pressing of the ENTER key.

Note

A protected file cannot be rotated.

Registering a File as the Startup Picture

You can register a picture file in the **Memory Stick** as the startup picture file which is displayed when the power is turned on.

Set “Startup” to “Entry”. When the file is registered, the startup mark is displayed.

When you want to use the registered picture file as the startup file, set “Startup” of the Setting screen to “Custom” (see page 26.)

To cancel the registration of the startup picture

- 1 Display the picture setting menu by selecting a thumbnail, select “Startup,” and press the ENTER key.
- 2 Press the ↓ or ↑ key to select “Cancel,” and press the ENTER key.

Note

As the setting of “Custom” is memorized in the **Memory Stick**, when you want to use the registered picture file as the startup file, insert the **Memory Stick** in the projector before turning on the projector.

Deleting a Picture File

You can delete the selected picture file or all picture files of the selected contents.

- 1 Select “Delete”, then press the ENTER key.
- 2 Select an item. When “Selected file deleted. OK?” or “All files deleted. OK?” is displayed, select “Yes”, then press the ENTER key.
All Img. : delete all picture files of the selected contents
Sel. Img. : delete the selected picture file
Close : when you do not want to delete the file

Note

A protected file cannot be deleted.

Showing/Hiding the Picture File Information

Select a picture file, select “Information” in “Menu” on the index screen of the full-screen still picture or on the Movie Player, then press the ENTER key. When you want to display the picture file information, select “On”. The information is displayed at the bottom of the screen. If you do not want to display the information, select “Off”.

When the Presentation Viewer is displayed, the number and size (resolution) of the picture file are displayed. When the Picture Viewer is displayed, the number, size (resolution), file format and recorded date of the picture file are displayed.

Note

For a picture file processed on a computer, the renewal date may be displayed instead of the recorded date.

Switching the Sound of a Movie File

- 1 Select a movie file, then press the ENTER key.
- 2 Select “Movie Player,” then press the ENTER key.
- 3 Select “Menu,” then press the ENTER key.
- 4 Select “Audio Select,” then press the ENTER key.
L/R : to hear the left and right sounds.
L : to hear the left sound.
R : to hear the right sound.

Notes

You cannot switch the sound of a Movie File in the following cases:

- When the audio sampling rate is incompatible.
- When the audio recording mode is monaural.
- When the audio recording mode is incompatible.

Sorting the Picture Files

You can sort the picture files in a folder by name or by renewal date in ascending/descending order.

- 1 Select “Option” in Memory Stick Home, then press the ENTER key.
- 2 Select “File”, then press the → or ENTER key.
- 3 Select “Sort”, then press the ENTER key.
- 4 Select the item you want to set, then press the ENTER key.

Note

For a picture file processed on a computer, the displayed data may be different from the renewal date.

Displaying Still Picture Files or Movie Files Only

You can filter all picture files contained in a folder to display the still picture files or the movie files only.

- 1 Select “Option” in Memory Stick Home, then press the ENTER key.
- 2 Select “File”, then press the → or ENTER key.
- 3 Select “Filter”, then press the ENTER key.
- 4 Select the item you want to set, then press the ENTER key.
Still : to display still pictures only
Movie : to display movie files only
Off : to display all files without filtering


Note

When the filter is set, the current filter name (Still or Movie) is displayed at the bottom right of Memory Stick Home.


Displaying the Picture Files Recorded by a Digital Camera Only


The unit can choose and display the JPEG and MPEG1 picture files recorded by a digital camera (DCF-compatible) only from among picture files stored in a **Memory Stick**.

- 1 Select “Select Folder” in Memory Stick Home, then press the ENTER key.
- 2 Select “Digi. Camera Mode”, then press the ENTER key.




- 3 Select “On”, then press the ENTER key.



+  (**Relative file mark**): Appears if another file with the same name in the last four figures is stored in the **Memory Stick**.

Notes


- This function does not work if more than 4000 picture files recorded by a digital camera are stored in a **Memory Stick**.
- For a picture file recorded with the Voice Memo function of a Sony digital camera, the still picture file is displayed only.
- If you delete a picture file with the relative file mark (+ ) , its related picture file will also be deleted.

Starting a Presentation Automatically — Autorun

When a **Memory Stick** with the picture file for which the Autorun function is set by the Projector Station for Presentation or “Setting the Autorun function” on page 13 is inserted in Memory Stick slot, the input is automatically switched to Memory Stick and the slide show starts.

To set the Autorun function

- 1 Select “Option” in Memory Stick Home, then press the ENTER key.
- 2 Select “Setting”, then press the ENTER key.
- 3 Select “Autorun”, then press the ENTER key.



- 4 Select “On”, then press the ENTER key.

When you do not want to use the autorun function

Set “Autorun” to “Off”.

Notes

- When the autorun is not set to “On” by the Projector Station for Presentation or “Setting the Autorun function” on page 13, you cannot use the autorun function to start the slide show even if you set “Autorun” to “On” in Memory Stick Home.
- When you want to use the autorun function for a picture file in the JPEG format, make the presentation material with the Projector Station for Presentation and set the autorun function to “On”.




Projecting a Selected File When the Power is Turned on — Startup

When the power is turned on, the selected picture file is projected for about 30 seconds.

When you want to use the registered picture file as the startup file, you must register a picture file as the startup file in the index screen (see page 22.)

- 1 Select “Option” in Memory Stick Home, then press the ENTER key.
- 2 Select “Setting”, then press the → or ENTER key.
- 3 Select “Startup”, then press the ENTER key.



- 4 Select the item, then press the ENTER key.

Original : select the original picture memorized in the projector
The original picture cannot be changed.

Custom : select the picture file registered in the index screen which is saved in **Memory Stick**

Off : when you do not want to set the startup


Notes

- When you want to use the registered file with the custom setting, insert the **Memory Stick** where the registered file is saved in the projector, then turn on the power.
- You can register one startup file per **Memory Stick**.

Displaying the Memory Stick Information

You can display the type and the used and remaining capacity of the **Memory Stick** in use. The remaining capacity of the **Memory Stick** is also displayed at the bottom right of Memory Stick Home.

- 1 Select “Option” in Memory Stick Home, then press the ENTER key.
- 2 Select “Memory Stick”.
The information of the **Memory Stick** in use is displayed.




To return to Memory Stick Home
Select “Close”.

Formatting a Memory Stick

When a **Memory Stick** cannot be used, format it with the projector.

When a **Memory Stick** is formatted, its data is cleared.

- 1 Select “Option” in Memory Stick Home, then press the ENTER key.
- 2 Select “Memory Stick”, then press the → or ENTER key.
- 3 Press the ENTER key again.



- 4 When “All files deleted. OK?” is displayed, select “Yes”, then press the ENTER key.
Formatting starts.

When you want to return to Memory Stick Home before formatting the Memory Stick
Select “Close”.

Notes

- When a **Memory Stick** is formatted, the protected picture file is also cleared.
- When a **Memory Stick** with the write-protect tab set to **LOCK** is to be formatted, “**Memory Stick locked**” is displayed.
- While formatting a **Memory Stick**, key operation in Memory Stick Home cannot be performed.






Troubleshooting

If you have a problem with Memory Stick Home, check the following. If the problem persists, contact your nearest Sony dealer.

Problem	Cause and solution
Cannot insert the Memory Stick into the drive.	<ul style="list-style-type: none"> The Memory Stick is not facing in the correct direction. → Insert the Memory Stick with the arrow mark pointing toward the Memory Stick slot of the projector.
Cannot save a file.	<ul style="list-style-type: none"> The Memory Stick is full. → Delete unwanted files in the Memory Stick. The write-protect tab on the Memory Stick has been set to LOCK. → Cancel the lock.
Cannot delete a file.	<ul style="list-style-type: none"> The write-protect tab on the Memory Stick has been set to LOCK. → Cancel the lock. The file is protected. → Release the protect in the Index screen.
Cannot delete all materials.	<ul style="list-style-type: none"> The write-protect tab on the Memory Stick has been set to LOCK. → Cancel the lock. The file is protected. → Release the protect in the Index screen.
Cannot format the Memory Stick .	<ul style="list-style-type: none"> The write-protect tab on the Memory Stick has been set to LOCK. → Cancel the lock. The Memory Stick is broken. → Use another Memory Stick.
Cannot access the Memory Stick inserted into the Memory Stick slot on the projector from the Projector Station for Presentation.	<ul style="list-style-type: none"> A Memory Stick inserted into the Memory Stick slot on the projector cannot be accessed from the Projector Station for Presentation. → Access the Memory Stick using a Memory Stick slot on your computer or an external USB device or an adaptor for the Memory Stick.
The still picture files in the JPEG format stored in a Memory Stick cannot be displayed.	<ul style="list-style-type: none"> A “Filter” is set in the “Option” menu. → Set “Filter” to “Still” or “Off.”
The movie picture files in the MPEG1 format stored in a Memory Stick cannot be displayed.	<ul style="list-style-type: none"> A “Filter” is set in the “Option” menu. → Set “Filter” to “Movie” or “Off.”
The picture is not projected and [?] or [] appears.	<ul style="list-style-type: none"> The file is not DCF-compatible. → Make the presentation material by using the Projector Station for Presentation.
Movies skip or stutter during playback.	<ul style="list-style-type: none"> This is not a unit malfunction. → For usable movie file format, see page 16.
Black bands appear on the upper and lower screen during playback of a movie on the full screen.	<ul style="list-style-type: none"> The setting of “Wide Mode” in the INPUT SETTING menu of the projector may be set to “On”. → For setting of “Wide Mode”, see Operating Instructions of the projector.


On Display


When the following displays appear in the screen, make the material for a presentation again using the Projector Station for Presentation.

	The picture file is in the unacceptable JPEG format or MPEG format.
	There is a thumbnail that it is not DCF-compatible.
	There is no selected picture file.
	There is a picture file but the thumbnail is broken.
	The picture file is broken.

Caution regarding messages while using a Memory Stick

Use the list below to check the message meanings.

Message	Solution
No Memory Stick	→ Insert a Memory Stick into the Memory Stick slot correctly.
No files that can be displayed.	→ No presentation files are contained in the Memory Stick . → Digital Camera Mode is selected, although no DCF compatible picture file are contained.
No files in this folder that can be displayed.	→ No picture files are contained in the currently selected folder.
No movie files in this folder that can be displayed.	→ No movie picture files are contained in the currently selected folder, although “Filter” is set to “Movie” in the “Option” menu.
No still files in this folder that can be displayed.	→ No still picture files are contained in the currently selected folder although “Filter” is set to “Still” in the “Option” menu.
Cannot play	→ The  key has been pressed while no movie picture files are contained in the selected folder. Slide show will not start.
Cannot play	→ Movie picture file(s) is damaged.
Memory Stick locked	→ The erasure prevention switch on the Memory Stick is set to LOCK. Release the lock.
Memory Stick error	→ The Memory Stick is damaged. → Clean the terminal on the Memory Stick . → The Memory Stick with memory select function has not been selected correctly with the memory select switch.
Memory Stick type error	→ A Memory Stick that is not compatible, or cannot be used with the projector has been inserted.



Other

Message	Solution
Format error	<ul style="list-style-type: none"> → The Memory Stick has not been formatted correctly. Format it on this projector correctly. → Formatting was not successful.
File error	<ul style="list-style-type: none"> → The selected folder has not been named correctly. → Enter the name again using less than 66 characters (including “/”) by displaying the Select Folder menu.
Read Only Memory	<ul style="list-style-type: none"> → A read-only Memory Stick containing picture files has been inserted. You cannot record or delete data with a read-only Memory Stick.
Access denied.	<ul style="list-style-type: none"> → A Memory Stick with Access Control from another unit is inserted. You cannot read/write data in this projector. To read/write data on a Memory Stick with Access Control, unlock the Memory Stick with the unit that has locked it.