19462 Powder Hill Place
Poulsbo, WA 98370
800.762.5757
360.779.7901
www.boxlight.com

USER MANUAL

TraveLight2

Copyright

This publication, including all photographs, illustrations and software, is protected under international copyright laws, with all rights reserved. Neither this manual, nor any of the material contained herein, may be reproduced without written consent of the author.

© Copyright January, 2006

Disclaimer

The information in this document is subject to change without notice. The manufacturer makes no representations or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. The manufacturer reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of the manufacturer to notify any person of such revision or changes.

Trademark Recognition

Kensington is a U.S. registered trademark of ACCO Brand Corporation with issued registrations and pending applications in other countries throughout the world.

All other product names used in this manual are the properties of their respective owners and are acknowledged.

Important Safety Information

Congratulations on purchasing the DLP projector!

> ***Important:***
> *It is strongly recommended that you read this section carefully before using the projector. These safety and usage instructions will ensure that you enjoy many years of safe use of the projector. Keep this manual for future reference.*

Symbols Used

Warning symbols are used on the unit and in this manual to alert you of hazardous situations.

The following styles are used in this manual to alert you to important information.

> ***Note:***
> *Provides additional information on the topic at hand.*

> ***Important:***
> *Provides additional information that should not be overlooked.*

> ***Caution:***
> *Alerts you to situations that may damage the unit.*

> ***Warning:***
> *Alerts you to situations that may damage the unit, create a hazardous environment, or cause personal injury.*

Throughout this manual, component parts and items in the OSD menus are denoted in bold font as in this example:
"Push the **Menu** button on the remote control to open the **Main** menu."

Remote Control

Some remote controls have a laser for pointing out items on a screen.
DANGER: Do not point the laser in the eyes. Doing so can damage the eyes permanently.

General Safety Information

- Do not open the unit case. Aside from the projection lamp, there are no user-serviceable parts in the unit. For servicing, contact qualified service personnel.
- Follow all warnings and cautions in this manual and on the unit case.
- The projection lamp is extremely bright by design. To avoid damage to eyes, do not look into the lens when the lamp is on.
- Do not place the unit on an unstable surface, cart, or stand.
- Avoid using the system near water, in direct sunlight, or near a heating device.
- Do not place heavy objects such as books or bags on the unit.

Power Safety

- Only use the supplied power cord.
- Do not place anything on the power cord. Place the power cord where it will not be in the way of foot traffic.
- Remove the batteries from the remote control when storing or not in use for a prolonged period.

Replacing the Lamp

Replacing the lamp can be hazardous if done incorrectly. Refer to “Replacing the Projection Lamp” on page 29 for clear and safe instructions for this procedure. Before replacing the lamp:

- Unplug the power cord.
- Allow the lamp to cool for about one hour.

Spent Lamp Management

- This product contains a metal halide lamp, which contains mercury. Dispose of it as required by local ordinances and regulations.
- The USA restricts or prohibits the disposal of some or all mercury containing lamps in the municipal waste stream. Please visit www.lamprecycle.org for more information on specific state disposal requirements and recycling facilities.
- The following states have laws that deal with information that wholesalers must provide to contractors for lamp disposal.
  Connecticut
  Maine
  Minnesota
  Rhode Island
- For users in Connecticut, please call our toll free number1-888-657-5267 to place an order for the delivery of a kit for returning a used lamp. The kit includes a box for the lamp, tape, and a return shipping label. To return a lamp:
  1. Place the lamp in the box, complete the enclosed form, and seal the box with the provided tape.
  2. Affix the return shipping label to the box and call 1.800.463.3339 FedEx Ground Service for box pickup.

Cleaning the Projector

- Unplug the power cord before cleaning. Refer to “Cleaning the Projector” on page 31.
- Allow the lamp to cool for about one hour.

Regulatory Warnings

Before installing and using the projector, read the regulatory notices in the “Regulatory Compliance” section on page 42.

Main Features

- *Lightweight unit, easy to pack away and transport*
- *Compatible with all major video standards including NTSC, PAL, and SECAM*
- *A high brightness rating allows for presentations in daylight or in lit rooms*
- *Supports resolutions up to SXGA at 16.7 million colors to deliver crisp, clear images*
- *Flexible setup allows for front and rear projections*
- *Line-of-vision projections remain square, with advanced keystone correction for angled projections*
- *Input source automatically detected*
- *Auto-keystone for easy keystone correction*

About this manual

This manual is intended for end users and describes how to install and operate the DLP projector. Wherever possible, relevant information—such as an illustration and its description—has been kept on one page. This printer-friendly format is both for your convenience and to help save paper, thereby protecting the environment. It is suggested that you only print sections that are relevant to your needs.

Table of contents

GETTING STARTED **1**

PACKING CHECKLIST 1
VIEWS OF PROJECTOR PARTS 2
Front-right View *2*
Top view—On-screen Display (OSD) buttons and LEDs *3*
Rear view *4*
Bottom view *5*
REMOTE CONTROL PARTS 6
REMOTE CONTROL OPERATING RANGE 7
PROJECTOR AND REMOTE CONTROL BUTTONS 8

SETUP AND OPERATION **9**

INSERTING THE REMOTE CONTROL BATTERIES 9
CONNECTING INPUT DEVICES 10
STARTING AND SHUTTING DOWN THE PROJECTOR 11
SETTING AN ACCESS PASSWORD (SECURITY LOCK) 12
ADJUSTING THE PROJECTOR LEVEL 13
ADJUSTING THE ZOOM, FOCUS AND KEYSTONE 14
ADJUSTING THE VOLUME 14
ADJUSTING WITH THE PROJECTOR QUICK MENU BUTTON 15

ON-SCREEN DISPLAY (OSD) MENU SETTINGS **16**

OSD MENU CONTROLS 16
Navigating the OSD *16*
SETTING THE OSD LANGUAGE 17
MAIN MENU 18
Main Menu Functions Available for Connected Source *19*
SETUP MENU 20
Setup Menu Functions Available for Connected Source *20*
Advance Feature *21*
User Color *23*
CONFIG MENU 24
UTILITY MENU 25
Utility Menu Functions Available for Connected Source *26*
LANGUAGE MENU 27
STATUS MENU 28

MAINTENANCE AND SECURITY **29**

REPLACING THE PROJECTION LAMP 29
Resetting the Lamp *31*
CLEANING THE PROJECTOR 31
Cleaning the Lens *32*
Cleaning the Case *32*
USING THE KENSINGTON® LOCK 32

TROUBLESHOOTING **33**

COMMON PROBLEMS AND SOLUTIONS 33
TIPS FOR TROUBLESHOOTING 33
LED ERROR MESSAGES 34
IMAGE PROBLEMS 34
LAMP PROBLEMS 35
REMOTE CONTROL PROBLEMS 35
AUDIO PROBLEMS 35
HAVING THE PROJECTOR SERVICED 36

SPECIFICATIONS **37**

SPECIFICATIONS 37
Input/output connectors *38*

PROJECTION DISTANCE V.S. PROJECTION SIZE 39
TIMING MODE TABLE 40
PROJECTOR DIMENSIONS 41

REGULATORY COMPLIANCE 42

FCC WARNING 42
CANADA 42
SAFETY CERTIFICATIONS 42
EN 55022 WARNING 42

Packing Checklist

Carefully unpack the projector and check that the following items are included:



DLP PROJECTOR WITH LENS CAP



REMOTE CONTROL (WITH ONE 3V CR2025 BATTERY)



POWER CORD



USB CABLE (USB TYPE A-TO-MINI USB)



S-VIDEO CABLE (MINI JACK-TO-S-VIDEO)



AUDIO CABLE (MINI JACK-TO-RCA X 2)



COMPUTER CABLE (DVI-DB15)



COMPOSITE VIDEO CABLE (MINI JACK-TO-RCA)

CD-ROM (THIS USER'S MANUAL)

QUICK START GUIDE



CARRYING CASE

Contact your dealer immediately if any items are missing, appear damaged, or if the unit does not work.

Caution:
Avoid using the projector in dusty environments.

Views of Projector Parts

Front-right View



ITEM	LABEL	DESCRIPTION	SEE PAGE:
1.	See "Top view—OSD buttons and LEDs" on next page		
2.	Rear IR receiver	Receiver for IR signal from remote control	*7*
3.	Lens zoom	Enlarges the projected image	*14*
4.	Focus	Focuses the projected image	
5.	Height-adjuster button	Push to release height adjuster	*12*
6.	Front IR receiver	Receiver for IR signal from remote control	*7*

Important:
Ventilation openings on the projector allow for good air circulation, which keeps the projector lamp cool. Do not obstruct any of the ventilation openings.

Top view—On-screen Display (OSD) buttons and LEDs



ITEM	LABEL	DESCRIPTION		SEE PAGE:
1.	Ready LED	Orange	Lamp ready—you can safely turn on or off the projector	
		Flashing	Lamp not ready—do not press the power button	
2.	Power LED	Green	Unit is powered on and working correctly	
		Off	Unit is powered off	
		Flashing	Operational error code (refer to "LED Error Messages" on page 34)	
3.	Power button	Turns the projector on or off		***11***
4.	Menu	Opens and exits the OSD		***16***
5.	Source/ Left cursor	Detects the input device Navigates and changes settings in the OSD		***11***
6.	Quick Menu/ Down cursor	Opens a Quick Menu for brightness, contrast, volume, and keystone adjustment Navigates and changes settings in the OSD		***15*** ***11***
7.	Auto/ Right cursor	Optimizes image size, position, and resolution Navigates and changes settings in the OSD		

Rear view



ITEM	LABEL	DESCRIPTION	SEE PAGE:
1.	Power	Connect the supplied power cord	***11***
2.	Rear IR receiver	Receiver for IR signal from remote control	***7***
3.	USB	Connect the USB cable from a computer	***10***
4.	Audio-in	Connect the audio cable from the input device	
5.	Video/S-video	Connect the composite or S-video cable from a video device	
6.	DVI-I	Connect the computer cable from a computer	
7.	Security Lock	Secure to permanent object with a Kensington® Lock system	***32***

Note:
If your video equipment has both S-video and RCA jacks (composite video) connect to the S-video connector.
S-video provides a better quality signal.

Bottom view



ITEM	LABEL	DESCRIPTION	SEE PAGE:
1.	Height-adjuster button	Push to release height adjuster	***12***
2.	Height adjuster	Adjusts level of projector	
3.	Projection lamp cover	Remove when changing lamp	***29***

Remote Control Parts



Important:
1. *Avoid using the projector with bright fluorescent lighting turned on. Certain high-frequency fluorescent lights can disrupt remote control operation.*

2. *Be sure nothing obstructs the path between the remote control and the projector. If the path between remote control and the projector is obstructed, you can bounce the signal off certain reflective surfaces such as projector screens.*

3. *The buttons and keys on the projector have the same functions as the corresponding buttons on the remote control. This user's manual describes the functions based on the remote control.*

ITEM	LABEL	DESCRIPTION	SEE PAGE:
1.	IR transmitter	Transmits signals to projector	
2.	Enter	Changes settings in the OSD	***16***
3.	Power	Turns the projector on or off	***11***
4.	Right cursor	Navigates and changes settings in the OSD Right arrow when connected through USB to a PC and OSD is Off	***16***
5.	Volume up	Adjusts volume	***14***
6.	Volume down	Adjusts volume	
7.	Mute	Mutes the built-in speaker	
8.	Freeze	Freeze/unfreezes the on-screen picture	
9.	Source	Detects the input device	***11***
10.	Auto	Auto adjustment for phase, tracking, size, position	
11.	Keystone bottom	Corrects image-trapezoid (wider bottom) effect	***14***
12.	Keystone top	Corrects image-trapezoid (wider top) effect	
13.	Down cursor	Navigates and changes settings in the OSD Down arrow when connected through USB to a PC and OSD is Off	***16***
14.	Left cursor	Navigates and changes settings in the OSD Left arrow when connected through USB to a PC and OSD is Off	
15.	Menu	Opens the OSD	
16.	Up cursor	Navigates and changes settings in the OSD Up arrow when connected through USB to a PC and OSD is Off	

Note:
The remote control can only interface with a computer when connected to the computer through a USB cable connection. The computer cable connects a computer to the projector for display purposes only.

Remote Control Operating Range

The remote control uses infrared transmission to control the projector. It is not necessary to point the remote directly at the projector. Provided you are not holding the remote perpendicular to the sides or the rear of the projector, the remote will function well within a radius of about 10 meters (33 feet) and 30 degrees above or below the projector level. If the projector does not respond to the remote control, move a little closer.

Projector and Remote Control Buttons

The projector can be operated using the remote control or the buttons on the top of the projector. All operations can be carried out with the remote control; however the buttons on the projector are limited in use. The following illustration shows the corresponding buttons on the remote control and on the projector.





Some buttons on the projector have two functions. For example, item 3/6 on the projector functions both as the source button and as the left cursor key in OSD menus.

Inserting the Remote Control Batteries

1. Remove the battery compartment cover by sliding the cover in the direction of the arrow.



2. Insert the supplied battery with the positive side facing up.



3. Replace the cover.



Caution:
1. *Only use a 3V lithium battery (CR2025).*

2. *Dispose of used batteries according to local ordinance regulations.*

3. *Remove the battery when not using the projector for prolonged periods.*

Remote Control Parts



Important:
1. *Avoid using the projector with bright fluorescent lighting turned on. Certain high-frequency fluorescent lights can disrupt remote control operation.*

2. *Be sure nothing obstructs the path between the remote control and the projector. If the path between remote and projector is obstructed, you can bounce the remote signal off certain reflective surfaces such as projector screens.*

ITEM	LABEL	DESCRIPTION	SEE PAGE:
1.	Laser	Use as on-screen pointer. DO NOT POINT IN EYES.	
2.	IR transmitter	Transmits signals to projector	*9*
3.	Status LED	Lights when the remote control is used	
4.	Auto	Optimizes image size, position, and resolution	
5.	Blank	Makes the screen blank	*22*
6.	Enter	Changes settings in the OSD	*17*
7.	Up cursor	Navigates and changes settings in the OSD	
8.	Right cursor		
9.	Cursor pad	Moves the on-screen cursor when connected to a PC	
10.	Keystone top	Corrects image-trapezoid (narrower top/bottom) effect	*15*
11.	Keystone bottom		
12.	Mute	Mutes the built-in speaker	
13.	Right mouse	Functions as right mouse button when connected to a PC	
14.	Left mouse	Functions as left mouse button when connected to a PC	
15.	Volume down	Adjusts volume	*16*
16.	Volume up		
17.	Down cursor	Navigates and changes settings in the OSD	*17*
18.	Left cursor		
19.	Menu	Opens the On-Screen Display (OSD)	
20.	Freeze	Freeze/unfreezes the on-screen picture	
21.	Source	Detects the input device	*13*
22.	Power	Turns the projector on or off	

Remote Control Operating Range

The remote control uses infrared transmission to control the projector. It is not necessary to point the remote directly at the projector. Provided you are not holding the remote perpendicular to the sides or the rear of the projector, the remote functions within a radius of about (7) meters (23 feet) and 30 degrees above or below the projector level. If the projector does not respond to the remote control, move a little closer.

Connecting Input Devices

A PC or notebook computer as well as video devices can be connected to the projector at the same time. Video devices include DVD, VCD, and VHS players, as well as movie camcorders and digital still cameras. Check the user manual of the connecting device to confirm it has the appropriate output connector.



ITEM	LABEL	DESCRIPTION
A	USB	Connect the supplied USB cable from a computer.
B	Audio-in	Connect an audio cable (not supplied) from the computer's audio-out connector. Connect the supplied audio cable (mini jack-to-RCA x 2) from a video device.
C	Video/ S-video	Connect the supplied composite video cable from a video device. Connect the supplied S-video cable from a video device.
D	DVI-I	Connect the supplied computer cable from a computer.

Warning:
As a safety precaution, disconnect all power to the projector and connecting devices before making connections.

Starting and Shutting down the Projector

1. Remove the lens cover.



2. Connect the power cord to the projector. Connect the other end to a wall outlet. The POWER and READY LEDs on the projector turn on.

3. Turn on the connected devices.

4. Ensure the Ready LED is on a steady (not flashing) orange and then press the **Power** button to turn on the projector.

   The projector splash screen displays and connected devices are detected.
   If the connected device is a PC, press the appropriate keys on the computer keyboard to switch the display output to the projector. (Check the user manual of the PC to determine the appropriate Fn key combination to change display output.)

   See "Setting an Access Password (Security Lock)" on page 12 if Security Lock is enabled.



5. If more than one input device is connected, press the **Source** button repeatedly to switch among devices.
   (DVD and HDTV are supported through the DVI-I connector.)



6. To turn off the projector, press the **Power** button. The projector prepares for shutdown and a "Wait a moment please…" message appears.

7. When the "Power Off?/Press Power again" message appears, press the **Power** button. The projector turns off.

Caution:
Do not unplug the power cord until the Ready LED stops flashing, indicating the projector has cooled down.

Setting an Access Password (Security Lock)

You can use the cursor (arrow) buttons to set a password and prevent unauthorized use of the projector. When enabled, the password must be entered after you power on the projector. (See "Navigating the OSD" on page 16 and "Setting the OSD Language" on page 17 for help on using OSD menus.)

> ***Important:***
> *Keep the password in a safe place. Without the password, you will not be able to use the projector. If you lose the password, contact your reseller for information on clearing the password.*

1. Press the **Menu** button to open the OSD menu.



2. Press the cursor ◄ ► button to move to the **Setup** menu.

3. Press the cursor ▲▼ button to select **Advance Feature** and press **Enter** or ►.

4. Press the cursor ▲▼ button to select **Security Lock**.



5. Press the cursor ◄ ► button to select **Enable**. (White text is selected.)
A password dialog box automatically appears.

6. You can only use the following three cursor buttons: ▼ ◄ ►
in the password fields. You can use any combination including the same arrow four times, but not less than four.
Press the cursor buttons in any order to set the password. When you confirm the password, **OK** appears.



Every time you start the projector, a password dialog box appears.

Enter the password in the order you set it at step 6. (Press the **Menu** button to cancel if you enter the wrong password.)



Adjusting the Projector Level

Take note of the following when setting up the projector:

- *The projector table or stand should be level and sturdy.*
- *Position the projector so that it is perpendicular to the screen.*
- *Be sure cables are not in the way or can cause the projector to be knocked over.*



7. To raise the level of the projector, lift the projector **[A]** and press the height-adjuster button **[B]**.

   The height adjuster drops down **[C]**.

8. To lower the level of the projector, press the height-adjuster button and push down on the top of the projector.

Adjusting the Zoom, Focus and Keystone

1. Use the **Image-zoom** control (on the projector only) to resize the projected image and screen size A.

2. Use the **Image-focus** control (on the projector only) to sharpen the projected image B.



3. Press the **Keystone** +/- buttons on remote control. The keystone control appears on the display. (See page 15 to adjust keystone with the Quick Menu button on the projector.)



4. Use the **Keystone** +/- buttons to correct image distortion.

Adjusting the Volume

1. Press the **Volume** +/- buttons on the remote control.
The volume control appears on the display. (See page 15 to adjust volume with the Quick Menu button on the projector.)



2. Use the **Volume** +/- buttons to adjust the level.

3. Press the **Mute** button to turn off the volume.

Adjusting with the Projector Quick Menu Button

Use the Quick Menu button on the projector to adjust brightness, contrast, volume, and keystone.

1. Press the **Quick Menu** button.
   The brightness control appears on the display.

2. Press the **Quick Menu** button repeatedly to scroll through the options contrast, volume, and keystone.

3. Use the ◄/Source and Auto/► buttons to adjust the value.

   The slider menu closes automatically.

ON-SCREEN DISPLAY (OSD) MENU SETTINGS

OSD Menu Controls

The projector has an OSD that lets you make image adjustments and change various settings.

Navigating the OSD

You can use the remote control cursor buttons or the buttons on the top of the projector to navigate and make changes to the OSD. The following illustration shows the corresponding buttons on the remote control and on the projector.



1. To open the OSD, press the **Menu** button.
2. There are six menus. Press the cursor ◄ ► button to move through the menus.
3. Press the cursor ▲▼ button to move up and down in a menu.
4. Press ◄ ► to change values for settings, and then press **Enter** or ► to confirm the new setting.
5. Press **Menu** to close the OSD or leave a submenu.



Note:
Depending on the video source not all items in the OSD are available. For example, the ***Horizontal/Vertical Position*** *items in the Setup menu can only be modified when connected to a PC. Items that are not available cannot be accessed and are grayed out.*

Setting the OSD Language

You may want to reference the OSD on your projector while reading this section. Set the OSD language to your preference before continuing. (The default language is English.)

1. Press the **Menu** button. The **Main** menu appears.



2. Press the cursor ◄ ► button until **Language** is highlighted.



3. Press the cursor ▲▼ button until the language you want is highlighted.
4. Press the cursor ► or **Enter** button to confirm the language.
5. Press the **Menu** button twice to close the OSD.

Main Menu

Press the **Menu** button to open the **OSD** menu. Press the cursor ◄► button to move to the **Main** menu. Press the cursor ▲▼ button to move up and down in the **Main** menu. Press ◄► to change values for settings, and then press **Enter** or ► to confirm the new setting.



ITEM	DESCRIPTION	DEFAULT
Brightness	Press the cursor ◄► button to adjust the brightness. (Range: 0 – 100)	50
Contrast	Press the cursor ◄► button to adjust the contrast. (Range: 0 – 100)	50
Sharpness	Press the cursor ◄► button to adjust the display sharpness (Range: 1-5)	3
Color Temperature	Press the cursor ◄► button to adjust the video tint/hue. (Range: Cool/Normal/Warm)	Normal
Color Saturation	Press the cursor ◄► button to adjust the video saturation. (Range: 0 – 100)	50
Color Tint	Press the cursor ◄► button to adjust the video tint/hue. (Range: 0 – 100)	50
Gamma	Press the cursor ◄► button to adjust the gamma correction of the display. **Input** **Gamma** **Brightness** PC 2.2 High MAC 1.8 High Video 2.4 Low Chart 2.2 Low B&W 2.4 High	PC
Color Space	Press the cursor ◄► button to adjust the color space. (Range: Auto – RGB – YPbPr- YCbCr)	Auto

ITEM	DESCRIPTION	DEFAULT
Reset	Resets all **Main** settings to default values	—

Main Menu Functions Available for Connected Source

Function	RGB	DVI	Component Video	Composite Video	S-video
Brightness	x	x	x	x	x
Contrast	x	x	x	x	x
Sharpness	x	x	x	x	x
Color Temp	x	x	x	x	x
Color Saturation			x	x	x
Color Tint			x	x	x
Gamma	x	x	x	x	x
Color Space	x	x	x	x	x
Reset	x	x	x	x	x

x = available to video source

Setup Menu

Press the **Menu** button to open the **OSD** menu. Press the cursor ◄► button to move to the **Setup** menu. Press the cursor ▲▼ button to move up and down in the **Setup** menu. Press ◄► to change values for settings, and then press **Enter** or ► to confirm the new setting.



ITEM	DESCRIPTION	DEFAULT
Horizontal Position	Press the cursor ◄► button to move the image left or right. (Range: 0 – 100)	50
Vertical Position	Press the cursor ◄► button to move the image up or down. (Range: 0 – 100)	50
Keystone	Press the cursor ◄► button to correct distortion of the projected image. (Range: -50 – +50)	0
Aspect Ratio	Press the cursor ◄► button to toggle between the 4:3 standard format and the 16:9 High Definition TV (HDTV) format.	4:3
Advance Feature	See "Advance Feature" on page 21.	—
Reset	Resets Keystone and Aspect Ratio to default values	—

Setup Menu Functions Available for Connected Source

Function	RGB	DVI	Component Video	Composite Video	S-video
H Position	x				
V Position	x				
Keystone correction	x	x	x	x	x
Aspect Ratio	x	x	x	x	x

Function	RGB	DVI	Component Video	Composite Video	S-video
Advance Feature	x	x	x	x	x
Reset	x	x	x	x	x

x = available to video source

Advance Feature

Press the **Menu** button to open the **OSD** menu. Press ◄► to move to the **Setup** menu. Press ▲▼ to move to the **Advance Feature** menu and then press **Enter** or ►. Press ▲▼ to move up and down in the **Advance Feature** menu. Press ◄► to change values for settings, and then press **Enter** or ► to confirm the new setting.



ITEM	DESCRIPTION	DEFAULT
User Color	This feature adjusts the color balance in each color of RGB (red, green, blue), and their neutral colors (cyan, magenta, yellow, white) by using color correction adjustment. Increasing a color's setting heightens the intensity of that color on the screen, while a lower setting makes the color less intense. Press ▲▼ to select a color. Press ◄► to adjust the selected color. (Range: 0 – 100)	80
White Peaking	White Peaking increases the output in the brightest whites without changing the blacks and dark grays. It crushes the whites slightly, but it does not appear to clip them or seriously obscure white detail. If you prefer a stronger image, adjust toward the maximum setting. For a smoother, more natural image, adjust toward the minimum setting. Press ◄► to adjust the value of white peaking. (Range: 0 – 10)	Data source: 10 Video source: 2
Logo Display	Press ◄► to enable or disable if the logo displays when the projector starts, and when no source is detected. (Range: On – Off)	On

ITEM	DESCRIPTION	DEFAULT
Auto Keystone	When enabled, keystone correction is automatically calibrated when you press the **Auto** button on the remote control or the keypad. Press ◄ ► to enable or disable Auto Keystone.	Off
AutoKeystone Calibrate	Press **Enter** or ► to automatically calibrate keystone correction.	—
Fan Speed	Press the cursor ◄ ► button to toggle between Normal and High fan speeds. Set Fan Speed to **High** in altitudes over 3,000 meters (10,000 feet).	Normal
Security Lock	Press the cursor ◄ ► button to enable or disable Security Lock. When you enable Security Lock a Register Password dialog box appears:  You can only use the following three cursor buttons, ▼ ◄ ► in the password fields. Press the cursor buttons four times in any order and confirm to set the password. When the password is enabled, it must be entered every time after you power on the projector. See "Setting an Access Password (Security Lock)" on page 12 for steps on setting the password.	No password
Reset	Resets White Peaking, Logo Display and Auto Keystone settings to default values	—

Note:
If Security Lock is enabled, you must enter the password every time the projector is turned on. However, if the projector is already turned on, Security Lock can be disabled without knowing the current password.

User Color

Press the **Menu** button to open the **OSD** menu. Press ◄►to move to the **Setup** menu. Press ▲▼ to move to the **Advance Feature** menu and then press **Enter** or ►. Press ▲▼ to move to the **User Color** menu and then press **Enter** or ►. Press ▲▼ to move up and down to select a color. Press ◄► to change values for settings, and then press **Enter** or ► to confirm the new setting.



ITEM	DESCRIPTION	DEFAULT
Red	Press the cursor ◄► button to adjust the red color level. (Range: 0 - 100)	80
Green	Press the cursor ◄► button to adjust the green color level. (Range: 0 - 100)	80
Blue	Press the cursor ◄► button to adjust the blue color level. (Range: 0 - 100)	80
Cyan	Press the cursor ◄► button to adjust the cyan color level. (Range: 0 - 100)	80
Magenta	Press the cursor ◄► button to adjust the magenta color level. (Range: 0 - 100)	80
Yellow	Press the cursor ◄► button to adjust the yellow color level. (Range: 0 - 100)	80
White	Press the cursor ◄► button to adjust the white color level. (Range: 0 - 100)	80
Reset	Resets all User Color settings to default values	—

Config Menu

Press the **Menu** button to open the **Main** menu. Press the cursor ◄► button to move to the **Config** menu. Press the cursor ▲▼ button to move up and down in the **Config** menu. Press ◄► to change values for settings, and then press **Enter** or ► to confirm the new setting.



ITEM	DESCRIPTION	DEFAULT
Blank Screen	Press the cursor ◄► button to select a background color for the blank screen. (Range: Black – Red – Green – Blue – White)	Blue
Auto Source	Press the cursor ◄► button to enable or disable automatic source detec-tion. (Range: On – Off)	On
Auto Power Off	Press the cursor ◄► button to enable or disable automatic shut-down of lamp after 10 minutes of inactivity. (Range: On – Off)	Off
Volume	Press the cursor ◄► button to adjust the audio volume level. (Range: 0 - 8)	4
Menu Position	Press the cursor ◄► button to position the OSD on screen. (Range: Left – Right – Center – Down – Up)	Center
Menu Display	Press the cursor ◄► button to determine the timeout delay of the OSD. (Range: 10 – 20 sec.)	15
Translucent Menu	Press the cursor ◄► button to set menu screen translucency. (Range: 0% – 100%)	0%
Reset	Resets all Config items to default values	

Note:
The Config menu functions are available to all video sources.

Utility Menu

Press the **Menu** button to open the **Main** menu. Press the cursor ◄► button to move to the **Utility** menu. Press the cursor ▲▼ button to move up and down in the **Utility** menu. Press ◄► to change values for settings, and then press **Enter** or ► to confirm the new setting.



ITEM	DESCRIPTION	DEFAULT
Video Type	Press the cursor ◄► button to select the video standard (Range: Auto – NTSC – PAL – SECAM)	Auto
Video AGC	Press the cursor ◄► button to enable or disable automatic gain control for the video source. (Range: On – Off)	On
Projection	Press the cursor ◄► button to choose from two projection methods: P Desktop mount, front of screen q Desktop mount, rear of screen	Desktop front P
Frequency	Press the cursor ◄► button to adjust the A/D sampling clock. (Range: 0° - 180°)	Auto detected
Tracking	Press the cursor ◄► button to adjust the A/D sampling number. (Range: 1 - 100)	Auto detected

ITEM	DESCRIPTION	DEFAULT
Digital Zoom	Digital operation for zoom and pan adjustment. Press **Enter** or ▶. The Zoom menu appears. Press ▲ to zoom in; press ▼ to zoom out. Press **Enter** or ▶ to open the Pan menu. (You must zoom in before you can open the Pan menu.)  Use the cursor buttons to pan the zoomed image. Press the **Menu** button to exit.	—
Reset	Resets Video Type, Video AGC, Projection, and Digital Zoom to default values	—

Utility Menu Functions Available for Connected Source

Function	RGB	DVI	Component Video	Composite Video	S-video
Video Type				x	x
Video AGC				x	x
Projection	X	x	x	x	x
Frequency	x		x		
Tracking	x				
Digital Zoom	x		x	x	x
Reset	x	x	x	x	x

x = available to video source

Language Menu

Press the **Menu** button to open the **Main** menu. Press the cursor ◄ ► button to move to the **Language** menu. Press the cursor ▲▼ button to move up and down in the **Language** menu. Press **Enter** or ► to confirm the new setting.



ITEM	DESCRIPTION	DEFAULT
English	Press the cursor ▲▼ button to move up and down in the menu. Press the **Enter** or ► to confirm the language.	English
French		
German		
Italian		
Spanish		
Swedish		
Chinese Simplified		
Chinese Traditional		
Japanese		
Korean		
Portuguese		
Russian		

Status Menu

Press the **Menu** button to open the **Main** menu. Press the cursor ◀ ▶ button to move to the **Status** menu. Press the cursor ▲▼ button to move up and down in the **Status** menu.



ITEM	DESCRIPTION	DEFAULT
Video Information	Displays the resolution and refresh rate for RGB/DVI mode. Displays the color standard for video mode.	These items are display only.
Active Source	Displays the active source.	
Software Version	Displays information about the software version.	
Lamp Hours	Shows the number of hours lamp has been in use for Eco and Normal modes.	
Lamp Mode	Press the cursor ◀ ▶ button to choose the lamp mode. Range: Eco; Normal. Eco mode uses less power and extends lamp life, but decreases lamp brightness.	Normal
Lamp Hour Reset	After replacing the lamp, this item should be reset. Refer to "Replacing the Projection Lamp" on page 29.	—

Replacing the Projection Lamp

The projection lamp should be replaced when it burns out. It should only be replaced with a certified replacement part, which you can order from your local dealer.

Important:
1. *The lamp contains a certain amount of mercury and should be disposed of according to local ordinance regulations.*

2. *Avoid touching the glass surface of the new lamp: Doing so may shorten its operation life.*

Warning:
Be sure to turn off and unplug the projector at least an hour before replacing the lamp. Failure to do so could result in a severe burn.

1. Loosen the two captive screws on the lamp compartment cover (**A**).

2. Remove the lamp compartment cover (**B**).



3. Remove the two screws from the lamp module (**A**).

4. Lift the module handle up (**B**).



5. Pull firmly on the module handle to remove the lamp module.

6. Reverse steps 1 to 5 to install the new lamp module.



Resetting the Lamp

After replacing the lamp, you should reset the lamp hour counter to zero. Refer to the following:

1. Press the **Menu** button to open the Main menu.

2. Press the cursor ◄ ► button to move to the **Status** menu.

3. Press the cursor ▲▼ button to move down to **Lamp Hour Reset**.



4. Press the cursor ► or **Enter** button.

   A message screen appears.

5. Press the cursor buttons in this order: ▼; ▲; ◄; ►.
   The **Status** menu appears again showing the **Lamp Hours** reset to zero.

Cleaning the Projector

Cleaning the projector to remove dust and grime will help ensure trouble-free operation.

Warning:
1. *Be sure to turn off and unplug the projector at least an hour before cleaning. Failure to do so could result in a severe burn.*

2. *Use only a dampened cloth when cleaning. Do not allow water to enter the ventilation openings on the projector.*

3. *If a little water gets into the projector interior while cleaning, leave unplugged in a well-ventilated room for several hours before using.*

4. *If a lot of water gets into the projector interior when cleaning, have the projector serviced.*

Cleaning the Lens

You can purchase optic lens cleaner from most camera stores. Refer to the following to clean the projector lens.

1. Apply a little optic lens cleaner to a clean soft cloth. (Do not apply the cleaner directly to the lens.)
2. Lightly wipe the lens in a circular motion.

> **Caution:**
> ***1.*** *Do not use abrasive cleaners or solvents.*
>
> ***2.*** *To prevent discoloration or fading, avoid getting cleaner on the projector case.*

Cleaning the Case

Refer to the following to clean the projector case.

1. Wipe off dust with a clean dampened cloth.
2. Moisten the cloth with warm water and mild detergent (such as used to wash dishes), and then wipe the case.
3. Rinse all detergent from the cloth and wipe the projector again.

> **Caution:**
> *To prevent discoloration or fading of the case, do not use abrasive alcohol-based cleaners.*

Using the Kensington® Lock

If you are concerned about security, attach the projector to a permanent object with the Kensington slot and a security cable.



> **Note:**
> Contact your vendor for details on purchasing a suitable Kensington security cable.
>
> The security lock corresponds to Kensington's MicroSaver Security System. If you have any comment, contact: Kensington, 2853 Campus Drive, San Mateo, CA94403, U.S.A. Tel: 800-535-4242, http://www.Kensington.com.

Common problems and solutions

These guidelines provide tips to deal with problems you may encounter while using the projector. If the problem remains unsolved, contact your dealer for assistance.

Often after time spent troubleshooting, the problem is traced to something as simple as a loose connection. Check the following before proceeding to the problem-specific solutions.

- *Use some other electrical device to confirm that the electrical outlet is working.*
- *Ensure the projector is turned on.*
- *Ensure all connections are securely attached.*
- *Ensure the attached device is turned on.*
- *Ensure a connected PC is not in suspend mode.*
- *Ensure a connected notebook computer is configured for an external display. (This is usually done by pressing an Fn-key combination on the notebook.)*

Tips for Troubleshooting

In each problem-specific section, try the steps in the order suggested. This may help you to solve the problem more quickly.

Try to pin point the problem and thus avoid replacing non-defective parts.
For example, if you replace batteries and the problem remains, put the original batteries back and go to the next step.

Keep a record of the steps you take when troubleshooting: The information may be useful when calling for technical support or for passing on to service personnel.

LED Error Messages

LED	STATUS/ NUMBER OF FLASHES	DESCRIPTION
Ready	Flashing	Lamp not ready—do not press the power button
	1	Fan1 error
	2	Fan2 error
Power	2	System task created error
	3	System overheating
	4	System interface error
	5	Lamp error
	6	Fan error (refer to Ready LED status to determine which fan)
	7	Lamp cover open
	8	DLP driver error
	9	Color wheel error

Image Problems

Problem: No image appears on the screen

1. Verify the settings on your notebook or desktop PC.
2. Turn off all equipment and power up again in the correct order.

Problem: The image is blurred

1. Adjust the **Focus** on the projector.
2. Press the **Auto** button on the remote control or projector.
3. Ensure the projector-to-screen distance is within the 10-meter (33-feet) specified range.
4. Check that the projector lens is clean.

Problem: The image is wider at the top or bottom (trapezoid effect)

1. Position the projector so it is as perpendicular to the screen as possible.
2. Use the Keystone button on the remote control or projector to correct the problem.

Problem: The image is reversed or upside down

Check the **Projection** setting on the **Utility** menu of the OSD.

Problem: The image is streaked

1. Set the **Frequency** and **Tracking** settings on the **Utility** menu of the OSD to the default settings.
2. To ensure the problem is not caused by a connected PC's video card, connect to another computer.

Problem: The image is flat with no contrast

Adjust the **Contrast** setting on the **Main** menu of the OSD.

Problem: The color of the projected image does not match the source image.

Adjust the **Color Temperature** and **Gamma** settings on the **Main** menu of the OSD.

Lamp Problems

Problem: There is no light from the projector

1. Check that the power cable is securely connected.
2. Ensure the power source is good by testing with another electrical device.
3. Restart the projector in the correct order and check that the Power LED is green.
4. If you have replaced the lamp recently, try resetting the lamp connections.
5. Replace the lamp module.
6. Put the old lamp back in the projector and have the projector serviced.

Problem: The lamp goes off

1. Power surges can cause the lamp to turn off. Press the power button twice to turn off the projector. When the Ready LED is on, press the power button.
2. Replace the lamp module.
3. Put the old lamp back in the projector and have the projector serviced.

Remote Control Problems

Problem: The projector does not respond to the remote control

1. Direct the remote control towards remote sensor on the projector.
2. Ensure the path between remote and sensor is not obstructed.
3. Turn off any fluorescent lights in the room.
4. Check the battery polarity.
5. Replace the battery.
6. Turn off other Infrared-enabled devices in the vicinity.
7. Have the remote control serviced.

Audio Problems

Problem: There is no sound

1. Adjust the volume on the remote control.
2. Adjust the volume of the audio source.
3. Check the audio cable connection.
4. Test the source audio output with other speakers.
5. Have the projector serviced.

Problem: The sound is distorted

1. Check the audio cable connection.
2. Test the source audio output with other speakers.
3. Have the projector serviced.

Having the Projector Serviced

If you are unable to solve the problem, you should have the projector serviced. Pack the projector in the original carton. Include a description of the problem and a checklist of the steps you took when trying to fix the problem: The information may be useful to service personnel. For servicing, return the projector to the place you purchased it.

Specifications

Display type	TI DMD 0.7-inch x 1, 12 degrees, DDR DLP with DDP 2000 ASIC controller
Resolution	XGA 1024 x 768 native
Color	16.7 Million (24-bits/pixel)
Bandwidth	Up to 140 MHz
Weight	<1.13 kg (<2.5 lbs.)
Projection distance	1.5 to 7 meters (59 to 276 inches)
Projection screen size	0.89 to 4.86 meters (35.15 to 191.38 inches)
Brightness uniformity	Typical 80%; minimum 70%
Projection lens	Manual and digital zoom; manual focus
Zoom ratio	1.16
Vertical keystone correction	+/- 15
Projection methods	Desktop front/rear
Data compatibility	IBM PC or compatibles (VGA, SVGA, XGA, SXGA, UXGA), Mac
SDTV/EDTV/HDTV	480i, 576i/480p, 576p/720p, 1080i
Video compatibility	NTSC/NTSC 4.43, PAL (B/G/H/I/M/N 60), SECAM
H-Sync	15,31 - 90 kHz
V-Sync	50 - 85 Hz
Safety certification	FCC Class B, UL, C-UL, CE, CB, TUV-CB, CCC
Operation temperature	5° C ~ 35° C
Dimensions	See “Projector Dimensions” on page 41
Power consumption	Typical 190W (normal mode); Typical 165W (ECO mode)
Stand By	< 8 watts
Lamp	Normal mode: 156W; Eco mode: 136W
Audio speaker	0.5W mono speaker

Input/output connectors

PC	DVI-I
	USB
Video	Mini-jack to composite video (RCAx1)
	Mini-jack to S-video (Mini-DIN)
Audio	Mini-jack
Security	Kensington slot

Projection Distance V.S. Projection Size



	Max. Screen Size (Wide)		1.8	Max. Screen Size (Tele)		2.1
Projection Distance L	Diagonal	Width A	Height C	Diagonal	Width B	Height D
1.00 m	0.69 m	0.56 m	0.42 m	0.60 m	0.48 m	0.36 m
3.28 '	27.34 "	21.87 "	16.40 "	23.43 "	18.75 "	14.06 "
1.50 m	1.04 m	0.83 m	0.63 m	0.89 m	0.71 m	0.54 m
4.92 '	41.01 "	32.81 "	24.61 "	35.15 "	28.12 "	21.09 "
2.40 m	1.67 m	1.33 m	1.00 m	1.43 m	1.14 m	0.86 m
7.87 '	65.62 "	52.49 "	39.37 "	56.24 "	44.99 "	33.75 "
2.80 m	1.94 m	1.56 m	1.17 m	1.67 m	1.33 m	1.00 m
9.18 '	76.55 "	61.24 "	45.93 "	65.62 "	52.49 "	39.37 "
3.20 m	2.22 m	1.78 m	1.33 m	1.90 m	1.52 m	1.14 m
10.50 '	87.49 "	69.99 "	52.49 "	74.99 "	59.99 "	44.99 "
3.60 m	2.50 m	2.00 m	1.50 m	2.14 m	1.71 m	1.29 m
11.81 '	98.43 "	78.74 "	59.06 "	84.36 "	67.49 "	50.62 "
4.00 m	2.78 m	2.22 m	1.67 m	2.38 m	1.90 m	1.43 m
13.12 '	109.36 "	87.49 "	65.62 "	93.74 "	74.99 "	56.24 "
4.40 m	3.06 m	2.44 m	1.83 m	2.62 m	2.10 m	1.57 m
14.43 '	120.30 "	96.24 "	72.18 "	103.11 "	82.49 "	61.87 "
4.80 m	3.33 m	2.67 m	2.00 m	2.86 m	2.29 m	1.71 m
15.74 '	131.23 "	104.99 "	78.74 "	112.49 "	89.99 "	67.49 "
5.20 m	3.61 m	2.89 m	2.17 m	3.10 m	2.48 m	1.86 m
17.06 '	142.17 "	113.74 "	85.30 "	121.86 "	97.49 "	73.12 "
5.60 m	3.89 m	3.11 m	2.33 m	3.33 m	2.67 m	2.00 m
18.37 '	153.11 "	122.48 "	91.86 "	131.23 "	104.99 "	78.74 "
7.00 m	4.86 m	3.89 m	2.92 m	4.17 m	3.33 m	2.50 m
22.96 '	191.38 "	153.11 "	114.83 "	164.04 "	131.23 "	98.43 "
10.00 m	6.94 m	5.56 m	4.17 m	5.95 m	4.76 m	3.57 m
32.80 '	273.40 "	218.72 "	164.04 "	234.35 "	187.48 "	140.61 "

Shaded rows are equivalent measurement in feet and inches

Timing Mode Table

The projector can display several resolutions. The following table outlines the resolutions that can be displayed by the projector.

Signal	Resolution	Frequency H. (KHz)	Frequency V. (Hz)	Video	Digital	Analog
NTSC	--	15.734	60.0	O	--	--
PAL / SECAM	--	15.625	50.0	O	--	--
VESA	640 x 350	37.9	85.1	--	O	O
	720 x 400	31.5	70.0	--	O	O
	720 x 400	37.9	85.0	--	O	O
	640 x 480	31.5	60.0	--	O	O
	640 x 480	37.9	72.8	--	O	O
	640 x 480	37.5	75.0	--	O	O
	640 x 480	43.3	85.0	--	O	O
	800 x 600	37.9	60.3	--	O	O
	800 x 600	46.9	75.0	--	O	O
	800 x 600	48.1	72.2	--	O	O
	800 x 600	53.7	85.1	--	O	O
	1024 x 768	48.4	60.0	--	O	O
	1024 x 768	56.5	70.1	--	O	O
	1024 x 768	60.0	75.0	--	O	O
	1024 x 768	68.7	85.0	--	O	O
	1280 x 1024	64.0	60.0	--	O	O
	1600 x 1200 **	75.0	60.0	--	--	O
Apple Macintosh	640 x 480	35.0	66.7	--	O	O
	832 x 624	49.7	74.5	--	O	O
	1024 x 768	60.2	74.9	--	O	O
	1152 x 870	68.7	75.1	--	O	O
HDTV	1920 x 1080	33.8	30.0	O	--	--
	1920 x 1080	28.1	25.0	O	--	--
	1280 x 720	45.0	60.0	O	--	--
SDTV	720 x 576	31.3	50.0	O	--	--
	720 x 480	31.5	60.0	O	--	--

O: Frequency supported

--: Frequency not supported

* The native resolution is 1024 x 768. Resolution other than native mode may be displayed with un-even size of text or lines.

** UXGA resolution with half-sampling

Projector Dimensions



REGULATORY COMPLIANCE

FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Changes or modifications not expressly approved by the parties responsible for compliance could void the user's authority to operate the equipment.

Canada

This class B digital apparatus complies with Canadian ICES-003.

Safety Certifications

UL, CUL, CB, TUV-GS, CCC

EN 55022 Warning

This is a Class B product. In a domestic environment, it may cause radio interference, in which case the user may be required to take adequate measures. The typical use is in a conference room, meeting room, or auditorium.